



BATTISTINIS CUSTOM CYCLES

1109 LANGTON DRIVE
SAN RAMON, CA 94582
925.270.4211 TECH LINE
WWW.BATTISTINISUSA.COM

06-818 CHROME BILLET RIDER FLOORBOARDS

BILL OF MATERIALS

Quantity	Part
1	Floorboard, left
1	Floorboard, right
4	Floorboard mount
16	$\frac{1}{4}$ -20 x $\frac{3}{4}$ " socket head cap screw
18	Rubber insert



 **MAINTENANCE:** To keep your new floorboards looking their best, apply a high-quality chrome polish to them every time you detail your motorcycle.

WARNING: Your safety depends on the correct installation of this kit. Use appropriate service manual procedures. If the procedures are not within your capability or you do not have the correct tools, have a trained mechanic/technician install this part for you. Improper installation of this part could result in injury or death.

STEP 1: Following the specifications listed in the appropriate service manual for your year and model of motorcycle, remove the existing floorboards. The OEM mounting hardware will be re-used in the installation of the Battistinis floorboards, so keep it with the motorcycle during the installation. Attach the floorboard brackets to the floorboards by matching the 4-hole pattern in the floorboard to each floorboard mount. Two mounts are used per floorboard, with 4 screws each. Apply a drop of Loctite 242 Blue to the threads of each bolt and secure the mounts to both floorboards. Torque the mount bolts to 80-lbs/in.



STEP 2: The Battistinis chrome billet floorboards install using the OEM shoulder bolts and locknuts. Following the specifications listed in the appropriate service manual for your year and model of motorcycle, install the Battistinis chrome billet floorboards. Verify the torque on all mounting hardware, and you are now ready to enjoy your Battistinis chrome billet floorboards.

