



Klock Werks FLARE Windshield Installation Instructions

Road Glide

Unscrew your current windshield and keep the screws, washers and rubber base trim. It is not necessary to reuse the rubber base trim, but you can if you wish. Using the stock screws, line up the windshield with the left screw hole while facing the front of the bike and screw it in ½ way. Line up the far right screw and screw it in ½ way. Proceed to screw in the rest of the screws and tighten all. NOTE: Be careful not to force fit the screws into the rubber “nuts” seated in the fairing or you may shove them thru and into the inside of the fairing.

“Batwing” Style

Unscrew your current windshield and keep the screws & washers. Separate the inner and outer fairing with your fingers and slide the shield in until it seats correctly and the inner and outer fairing fits snug on both sides. Replace all screws and washers by putting them all in ½ way, then tighten all. NOTE: Do not over tighten or you may pull brass bushings out.