

Harley-Davidson Wheel Chart

Model	Year	Factory Combination		Suggested Combination	
		Front	Rear	Front	Rear
Dyna	06-'10	19x2.15	17x5.0	19x2.15	18x5.5
		100/90/19	160/70/17	100/90/19	180/55/18
	95-'05	19x2.15	16x3.0	19x2.15	18x3.5
		100/90/19	140/90/16	100/90/19	150/70/18
Dyna Wide Glide	06-'10	21x2.15	17x5.0	21x2.15	18x5.5
		90/90/19	160/70/17	90/90/21	180/55/18
	95-'05	21x2.15	16x3.0	21x2.15	18x3.5
		90/90/19	140/90/16	90/90/21	150/70/18
Fat Boy	07-'10	17x3.5	17x6.0	18x3.5	17x6.25
		140/75/16	200/55/17	130/70/18	200/55/17
	84-'06	16x3.5	16x3.0	18x3.5	18x3.5
		130/90/16	140/90/16	130/70/18	150/70/18
Softail	06-'10	21x2.15	17x6.0	21x2.15	17x6.25
		90/90/21	200/55/17	90/90/21	200/55/17
	84-'05	21x2.15	16x3.0	21x2.15	18x3.5
		90/90/21	140/90/16	90/90/21	150/70/18
Sportster	80-'10	21x2.15	16x3.5	21x2.15	18x3.5
		90/90/19	140/90/16	90/90/19	150/70/18
Touring	2010	18x3.5	16x5.0	21x3.5	17x6.25
		130/70/18	180/65/16	120/70/21	200/50/17
	2009	17x3.5	16x5.0	21x3.5	17x6.25
		130/80/17	180/65/16	120/70/21	200/50/17
95-'08	16x3.5	16x3.0	18x3.5 or 21x3.5	18x3.5 or 18"x4.25	
		130/90/16	140/90/16	120/70/21 or 140/70/18	150/70/18*

Notes	
Dyna Models	No modifications necessary on a rear 180/55/18 upgrade
Touring	Fender modifications necessary when installing a 21" front wheel. RC Components recommends drilling out rear mounting holes using a 3/8" drill bit allowing clearance for tire growth
	No modification necessary when installing up to a 200 rear tire upgrade on '09-'10 touring models
	Avon Storm AV56 200/50ZR-17 tire is the #1 recommended choice for 17x6.25 rear wheels on '09-'10 touring models
	'09-'10 Screamin' Eagle touring models require new fender brackets for 21" front wheels
	95-03 FLH rear requires 3/16" pulley spacer for 150 rear tire